

ST104421M Panel

High speed, High Accuracy. The most trustworthy electrical control partner.

Basic Installation Instructions v1.0

Dear users, please go through the instructions in detail before the installation. Also, please hand the manual to the actual operator of the machine and preserve it properly.

Second panels are precision electronic devices. For the safety of both operators and the machine, all installations, tests, and adjustments shall be operated by professional personnel. Heed all the descriptions with “DANGER,” “WARNINGS,” and “CAUTION” in the manual. For help and service, please contact the branches in each region. Our professionals are glad to be at your service.

1. Safety Precautions

Please pay extra attention to the instructions below while operating the product.

DANGER

- The panel series is to control the machine tool and the IO control. Do not touch the internal circuits or components while the controller is powered up.
- The internal circuit board of the driver contains CMOS ICs, which are vulnerable to static electricity. Do not touch the circuit board with hands before taking any precautions.

WARNING

- The panel is a precision device. Non-maintenance staff or non-professional electronic control personnel shall not disassemble the panel.

CAUTION

- Please install the panel in a safe area and keep it clean. Please keep iron shavings, wires, water, corrosive gas, and liquid from the IPC to avoid malfunction.
- Storage temperature range: -40°C~70°C
- Storage humidity range: 0% to 90% and without condensation.
- Operating temperature range: -10°C~55°C
- Please reserve at least 50mm in width for ventilation and heat dissipation.
- The grounding of the panel and the machine tool is necessary for leakage protection and prevention of lightning strikes. Please ensure the system and the machine tool are grounded properly before installing.
- The rated voltage of the panel power system shall not exceed 5V±20%. If the operation area provides an unstable voltage source, please apply a voltage stabilizer so that the panel can function normally.
- Please turn off the power before plugging/unplugging the cables. Otherwise, it may cause damage to the panel or electric shock.
- Please ensure all the terminals are in correct positions while wiring to prevent the panel from damage caused by wiring mistakes.


2. Interface Specifications

(Front View)




A	Keys	Power switch	D	Knobs	Band selections
B	Keys	Function selection of the machine	E	Keys	Execute/Stop the program
C	Button	Emergency-stop switch			

(Rear View)




A	7P Connector	Band data output switches
B	Working power of the panel & Extension Point O Port	For 5V working power input of the panel & the output of the extension point O
C	Push Button Switch	Execute/Stop the program
D	Push Button Switch	Power switch
E	Extension Point I Port	Extension Point I for customers' use
F	I/O data input/output port	Connect to the PIO5-XO7 or the AIO H/K Port
G	Emergency Stop Connector	Emergency Stop for self-wiring

3. External Dimensions (Unit : mm)




4. Installation Specifications (Unit : mm)

(Front View)



5. Mounting Hole Specifications (Unit : mm)




6. Parameter Setting of the Controller

No.	Description	Input Range	Input Value
3217	Select the type of the keyboard of the controller panel.	[0,3217]	1

7. I/O Arrangement

IO Corresponding Graph of Product Keys: The corresponding point of I & O



8. Interface Configurations

Please notice the value and polarities of voltages.

● HK Connector Arrangement

HK	PIN	SIGNAL	PIN	SIGNAL
	26	—	25	XDI55
	24	XDI54	23	XDI53
	22	XDI52	21	XDI51
	20	XDI50	19	XDI49
	18	XDI48	17	5V
	16	GND	15	XDO62
	14	XDO61	13	XDO60
	12	XDO59	11	XDO58
	10	XDO57	9	XDO56
	8	XDO55	7	XDO54
	6	XDO53	5	XDO52
	4	XDO51	3	XDO50
	2	XDO49	1	XDO48

9. HK Keyboard Specifications

Icon	Function	Operating Procedures
	MPG analog mode: Check the NC program with this method.	<ol style="list-style-type: none"> Turn the mode button to AUTO. Press MPGSIM and the button light will be illuminated. Press START to execute the NC program. The CNC will change the status of the machine from “READY” to “PROCESSING.” Rotate the “rotating MPG” if the machine is not moving. The faster the MPG (rotating handwheel) rotates, the faster the machine moves. The CNC stops when the MPG stops. Whether the program can process can be known from this method.
	Single Block Executing: Test the NC program with this method.	<ol style="list-style-type: none"> Turn the mode button to AUTO. Press SBK and the button light will be illuminated. Press START to execute the NC program. The CNC will execute the NC program for only a block and stop. The CNC will change the status of the machine from “PROCESSING” to “STOP.” Press START again, and the CNC will execute the next block. This function is for checking the program block by block.
	JOG mode: Control the movement of machines with this method.	<ol style="list-style-type: none"> Turn the mode button to JOG. Control “X+, X-, Y+, Y-, Z+, Z-” according to the movement direction of the motor. With the band, operators can adjust the cutting amount in the JOG mode. Press the “machine movement key” and the “fast displacement key” at the same time, and the CNC motor will move at the speed of “G00.” Use the feed rate with G00% to move the

		machine. (6) This function is for checking the program block by block.
	Optional Stop: Set the M01 of the NC program to stop or not with this method.	<ol style="list-style-type: none"> Turn the mode button to AUTO. Press O.STOP and the button light will be illuminated. Press START to execute the NC program. When “M01” is in the CNC execution program, the CNC will stop. The status of the CNC will change from “PROCESSING” to “STOP.” This mode is for tool change and workpiece inspection.
	Optional Single Block Jump: With this function, define the machine to run or to jump when meets “/.”	<ol style="list-style-type: none"> Turn the mode button to AUTO. Press B.D.T and the button light will be illuminated. Press START to execute the NC program. When the CNC meets “/,” it will jump the block automatically. If did not press the button, the CNC will run this block.
	MAG. POP/PUSH: Pop-out or put in the tool machine.	
	MAG. CW/CCW: Rotate the tool magazine clockwise/ counterclockwise.	
	MAG. CW/CCW: Rotate the tool magazine clockwise/ counterclockwise.	
	COOLANT: Turn on/off the fluid switch.	
	Spindle CW: Rotate the spindle clockwise.	
	Spindle Stop: Stop the spindle.	


	Spindle CCW: Rotate the spindle counterclockwise.		LIGHT: Turn on/off the working light.
	Spindle Locating: Stop the spindle at a set corner.		Air blow: Control the air switch.

10. Wiring Notifications

- When using a solenoid valve or other inductive loads, please apply an arc extinguisher or an RC varistor to ensure the life of the contact points. Advantages of the arc extinguisher:
 - Extend the life of electrical contacts.
 - Reduce the sparks from the contact points.
 - Restrain the impulse voltage.
 - Prevent inductive loads from interferences caused by back-EMF.
- Please crimp or weld the wire connections while wiring.
- The external 5V power supply used in wiring shall be certificated and protective to avoid the malfunction caused by wiring mistakes. (Recommendation standard: fulfill requirements of EN60950 and UL1950)

- Only dry contact switches can be used for the extension I point.**

Circuit Example:



- Extension O point can only drive LEDs without current limiting resistors.**

Circuit Example:

